




ITEM NO.	NO.	PART NO.	NAME
YT-82794 & YT-82795	1	ZY8279401	CHUCK SCREW
	2	ZY8279402	CHUCK
	42	ZY8279442	SPEED SELECTOR BUTTON
	43	ZY8279443	LEVER
	44	ZY8279444	THE TAIL OF HIGH
	45	ZY8279445	LEFT HOUSING
	47	ZY8279447	CONTROL CIRCUIT BOARD
	53	ZY8279453	RIGHT HOUSING
	55	ZY8279455	BATTERY PACK
		ZY8279456	CHARGER
	3,4,5,6,7,8,9, 10,11,12,13, 14,15,16,17, 18,19,20,21, 22,23,24,25, 26,27,28,29, 30,31,32,33,	ZY827941A	GEAR ASSEMBLY
	37.38	ZY827942A	MOTOR WITH GEAR